# 3M<sup>™</sup> Digital Projector

## File Transfer Tool Guide Version 1.0

For Models: X62w / X64w / X90w / X95

## **Revision History**

| Revision Date | Page(s) Changed | Description of Change   |
|---------------|-----------------|-------------------------|
| 4/2009        | All pages       | First edition released. |
|               |                 |                         |

#### Intended Use

The 3M™ Digital Projectors are designed, built, and tested for use indoors, using 3M lamps, 3M ceiling mount hardware, and common line voltages (100V to 240V AC, 50/60 Hz). The use of other replacement lamps, outdoor operation, or different voltages has not been tested and could damage the projector, peripheral equipment and/or create a potentially unsafe operating condition.

3M Digital Projectors are designed to operate in a normal office environment.

- 100V 240V AC, 50/60 Hz
- 16° to 29° C (60° to 85° F)
- 10-80% RH (without condensation)
- 0-1828m (0-6000 feet) above sea level

The ambient operating environment should be free of airborne smoke, grease, oil and other contaminates that can effect the operation or performance of the projector.

The 3M logo and 3M are trademarks of the 3M Company. Other trademarks used herein are the properties of their respective owners.

#### **Important Notice**

All statements, technical information, and recommendations related to 3M's products are based on information believed to be reliable, but the accuracy or completeness is not guaranteed. Before using this product, you must evaluate it and determine if it is suitable for your intended application. You assume all risks and liability associated with such use. Any statements related to the product which are not contained in 3M's current publications, or any contrary statements contained on your purchase order shall have no force or effect unless expressly agreed upon, in writing, by an authorized officer of 3M.

#### **Warranty and Limited Remedy**

3M warrants that when the 3M Product is used according to 3M's Intended Use Statement (www.3M.com/meetings), it will perform satisfactorily for the warranted durability period as stated in the applicable 3M Product Manual in effect at the time of purchase. The warranties stated in the applicable 3M Product Manuals are exclusive and are made in place of any and all express or implied warranties or conditions, including any implied warranty of merchantability or fitness for a particular purpose, or any industry practice or custom or trade usage. Failure to follow the instructions contained in the appropriate 3M Product Manual or to use the 3M Product in accordance with 3M's Intended Use Statement will void all warranties and limited remedies.

EXCEPT AS SPECIFICALLY STATED IN THE APPLICABLE 3M PRODUCT MANUAL, 3M SHALL NOT BE LIABLE FOR ANY INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, LOSS OF PROFITS, REVENUE OR BUSINESS) RESULTING FROM, OR IN ANY WAY RELATED TO PERFORMANCE, USE OR INABILITY TO USE ANY OF THE 3M PRODUCT.

This limitation applies regardless of the legal theory upon which damages are sought. If 3M Product is defective within the applicable warranty period, your exclusive remedy shall be, at 3M's option, to replace or repair the 3M Product or to refund the purchase price of the 3M Product. All replaced parts or products become property of 3M. If the 3M Product is repaired, 3M will repair the defective part(s) with a new or used part(s). If the 3M Product is replaced, 3M will replace the product with the same or equivalent model and with a new or refurbished product. In the case of an approved warranty claim, the replacement 3M Product will carry only the remaining term of the original 3M Product's warranty period as stated in the applicable 3M Product Manual.

For warranty service, you must provide proof of the date of the original purchase, otherwise the manufacturing code date will be used to establish the start date of the warranty. 3M Product Manuals include durability statements and may include limitations specific to the product(s) being used or its intended applications, which take precedence over any statement made here. Warranty terms, limitations and exclusions may differ outside the United States of America.



#### Contents

| 1 | INT   | RODUCTION                                 | . 3 |
|---|-------|---|-----|
| 1 | .1    | OUTLINE                                   | . 3 |
| 1 | .2    | System                                    | . 3 |
| 2 | INS   | TALLATION                                 | . 4 |
| 2 | 2.1   | SYSTEM REQUIREMENTS                       | . 4 |
| 2 | 2.2   | PROJECTOR FILE TRANSFER TOOL INSTALLATION | . 4 |
| 3 | OPE   | ERATING INSTRUCTIONS                      | . 6 |
| 3 | 3.1   | CREATE LOGIN ACCOUNTS                     | . 6 |
| 3 | 3.2   | START APPLICATION                         | . 8 |
| 3 | 3.3   | QUIT APPLICATION                          | . 8 |
| 3 | 3.4   | MAIN SCREEN                               | . 9 |
| 3 | 3.5   | CONNECT TO THE PROJECTOR                  | 10  |
| 3 | 3.6   | TRANSFER FILE                             | 13  |
| 3 | 3.7   | CREATE FOLDER                             | 14  |
| 3 | 8.8   | DELETE FOLDER OR FILE                     | 14  |
| 3 | 3.9   | Assign a file to E-SHOT IMAGE             | 14  |
| 3 | .10   | ABOUT THIS APPLICATION                    | 14  |
|   | 1 184 | IT A TIONIC                               | 4 5 |

- · Microsoft and Windows is the registered trademark of Microsoft Corporation in the US and other countries.
- · Pentium is the registered trademark of Intel Corporation in the US and other countries.
- All other trademarks are the property of their respected owners.

#### Warning

- This software is free via download. The manufacturer has no responsibility for any errors that may occur while using this software.
- This software, or any product used with this software may not be used for any act which obstructs the Maintenance
  of the International Peace and Safety.

## 1 Introduction

#### 1.1 Outline

Projector File Transfer Tool allows you to transfer computer files to a storage media (SD memory card or USB flash drive) that is connected to the X62w, X64w, X90w or X95 through the network. The supported file formats are text, jpeg, ping and bitmap (txt, jpg, jpeg, png, bmp) and the file name has to be ASCII (expects \(\frac{1}{2}\);\*?"<>|).


An image number for e-SHOT feature is able to assign to the transferring file. The e-SHOT is available from [MIU] → [e-SHOT] menu on the projector.

#### [Note]

- The network configuration is required to transfer files from computer to projector. Please check the User's Manual-Network Functions for network configuration.
- The storage media (SD memory card or USB flash memory) is required to use this feature. Please check the User's Manual-Network Function for compatible media.
- Please check User's Manual-Operating Guide for e-SHOT feature.

#### 1.2 System

The following diagram shows a typical network diagram for the Projector Image Tool



X62w / X64w / X90w / X95

> Use a UTP cable Category 5 or higher for a Local Area Network cable.

## 2 Installation

#### 2.1 System Requirements

The following is the minimum system requirements for hardware & software.

(1) Operating System
Windows 2000 Professional
Windows XP Home Edition
Windows XP Professional
Windows Vista

(2) CPU Pentium3 500MHz or higher

(3) Memory 128MB or higher

(4) Hard Disc Minimum 3MB free space for installation.

- (5) Wired LAN or Wireless LAN Required for transfer files,
- (6) Storage Media (SD memory, USB Memory etc.) Required for store the file on the projector.

#### 2.2 Projector File Transfer Tool Installation

- (1) Double click the file "InstForPJTransfer.exe".
- (2) Select the language (English, Japanese or Chinese [Simplified]) during the installation process. And then click [OK].




(3) Click [Next]

(4) Read "License Agreement" and select "I accept the Functions of the license agreement" and click [Next] to agree.

Otherwise, click [Cancel] and stop the installation.





(5) Confirm the program folder, and then click [Next].




(6) Confirm the install folder and program folder again, and then click [Next].







(7) Click [Finish] to complete the Projector File Transfer Tool setup wizard.




## 3 Operating Instructions

#### 3.1 Create login accounts

The Projector File Transfer Tool requires a login name and password to launch the software. The Projector User Administration Tool helps you to create new user accounts.

#### 3.1.1 How to launch

Double Click "PJUsrEdit.exe" that is located on the same folder as the installed Projector File Transfer Tool. It automatically launches the Projector User Administration Tool, if no user accounts are created yet. Also, Projector File Transfer Tool has a short cut [File] → [User Configuration] to launch Projector User Administration Tool.



#### 3.1.2 How to exit

Select [File]  $\rightarrow$  [Exit] from the menu or click [x] in the top right corner. If changes are made, you will be required to confirm the changes.

#### 3.1.3 Main Window



#### (1) Menu

| Menu | Sub Menu     | Description         |
|------|--------------|---------------------|
| File | Save         | Save user data      |
|      | Exit         | Exit                |
| Edit | Add New User | Create new user     |
|      | Change User  | Edit user account   |
|      | Delete User  | Delete user account |

#### (2) User List

The status in the User List is described below.

| Row name    | Description  |  |
|-------------|--|--|
| User Name   | Username (ID)  |  |
| Description | Comment  |  |
| Man         | "●" shows that the user can access to the PJMan (Projector Management Application).  |  |
| Ctrl        | Ctrl "•" shows that the user can access to the PJCtrl (Projector Control Tool).      |  |
| FTP         | "●" shows that the user can access to the PJTransfer (Projector File Transfer Tool). |  |

#### 3.1.4 Creating new user account

Select [Edit] → [Add New User] or right click on the user list and select [Add New User]. The following dialog window appears.

User Name --- Define user name, up to 20 characters
Description --- Add comments, up to 50 characters
User Rights --- Define accessibility. It defines

Define accessibility. It defines the accessibility for the application software by each user account. The user can use allocation only marked application

software.

Select All --- Select all application software.
UnSel All --- Unselect all application software.

Press [OK] button after entering user name. The [Change Password] dialog appears. Enter new password and confirm entered password. The password is up to 20 characters and case sensitive.





#### 3.1.5 Edit user account

Double click a username on the user list or select [Edit] → [Change User] after choosing user to open edit dialog. You can edit username, description and accessibility (user rights).

Click the button to change password. Enter old and new password, and re-enter new password to confirm.





#### 3.1.6 Delete user account

Select [Edit] → [Delete User] or right click on the user list and select [Delete User]. The confirmation window will appear.

#### 3.1.7 Save user account


Select [File]  $\rightarrow$  [Save]. The date is stored in the file, "C:\Program Files\Common Files\HITACHI\Projector Tools\config\UserList".


#### 3.2 Start Application

Select Windows [Start] → [Program] → [Projector Tools] → [Projector File Transfer Tool]. The login window will appear.

Enter the username and password that is created by "Projector User Administration Tool".

The following window will appear.





Local Tree View

Displays local computer directories or files.

**Projector Tree View** 

Displays storage media folders or files that are connected to the projector.

Folder or file names must have ASCII characters (except \(\frac{4}{.},\),\*?"<>|) and the file extention must be txt, jpg, jpeg, png or bmp. You can transfer the file both ways between computer and projector.

#### 3.3 Quit Application

Select [File] → [Exit] to quit.

It is also possible to quit this software by clicking [x] on the top right corner of the window.

When the confirmation dialogue appears, select [OK] to finish.



## 3.4 Main Screen

## (1) Menu

The functions of the main window are as follows.

| Menu      | Sub-Menu             | Function  |  |
|-----------|----------------------|---|--|
| File      | Update               | Update tree views   |  |
|           | User Configuration   | Launch Projector User Administration Tool.                    |  |
|           | Exit                 | Quit Application.   |  |
| Projector | Connect              | Connect to the projector                                      |  |
|           | Disconnect           | Disconnect the projector                                      |  |
| Tool      | Create Folder        | Create new folder   |  |
|           | Delete               | Delete a folder or file,                                      |  |
|           | Image-1              | Assign or clear e-SHOT number "Image-1" to the selected file. |  |
|           | Image-2              | Assign or clear e-SHOT number "Image-2" to the selected file. |  |
|           | Image-3              | Assign or clear e-SHOT number "Image-3" to the selected file. |  |
|           | Image-4              | Assign or clear e-SHOT number "Image-4" to the selected file. |  |
| Help      | About Projector File | Display the version of this application.                      |  |
|           | Transfer Tool        |   |  |

## (2) Toolbar


The functions of these icons correspond with the menus as follows:

| Icon     | Menu   |
|----------|--|
| <b>a</b> | [Projector] - [Connect]                      |
| ă        | [Projector] - [Disconnect]                   |
|          | [Tool] - [Create Folder]                     |
| 1        | [Tool] - [Delete]                            |
| 1        | [Tool] - [Image-1]                           |
| 2        | [Tool] - [Image-2]                           |
| 3        | [Tool] - [Image-3]                           |
| 4        | [Tool] - [Image-4]                           |
| ?        | [Help] - [About Projector File Transfer Tool |

#### 3.5 Connect to the projector

#### 3.5.1 Register Projector

Selects [Projector] → [Connect] from menu or click icon on the tool bar. The [List of Projector] dialog will appear.



#### **Discovery**


The discovery feature allows you to search projectors on the network automatically.

#### [NOTE]


Windows Security Alert will be shown on your display when the discovery function activates, if Windows Firewall is "On" on Windows XP SP2 or later. Please choose "Unblock" to add the software onto the exception list. Also other firewall security software may block the discovery function. In that case, please add the software to the safe list or disable firewall software when you use the discovery function.

Choose your computer IP address and click start button. The discovery starts to search projectors on the network and shows a result on the discovery window.





The Discovery feature will register all found projectors. Click the [Close] button to end.



#### Add

Create new projector and add into the list. The following window will appear.

#### General TAB

General settings for FTP connection.

Projector Name --- Enter projector name


IP Address --- Enter IP address of projector

User ID --- Enter username for FTP connection.
The default of user name is "projector".

Password --- Enter password for FTP connection.

The password is mask by \*. The default

password is "projector".



#### **Command Control TAB**

The setting of projector command protocol. This setting is required for controlling the storage media by projector internal command.

Port No --- Enter TCP/IP port number.

Authentication --- Mark when the projector authentication is

enabled.

Auth Password --- Enter authentication password.



#### Edit


Edit existing projector setting. Select a projector from the list and then click the [Edit] button.

#### Delete

Delete selected projector on the list. The confirmation message will appear.


#### 3.5.2 Connection

In order to make a connection with a projector, please select a projector from the [List of Projector] dialog and click the [Connect] button. The projector will display on the projector tree view, when the FTP connection is established.



List of Projector

If the projector has two types of media both SD memory card and USB flash drive, the media will be shown as separate folders. See the example below.




#### 3.5.3 Disconnect

Select [Projector] → [Disconnect] from the menu or click icon on the tool bar to disconnect a projector. The following confirmation message will appear.




#### 3.6 Transfer file

In order to transfer file(s), drag and drop a folder or file onto the projector tree view.



The progress status window will be shown during the transfer process. To cancel the process click the [Cancel] button.



When the transfer is complete, the following message will appear.


Also, if a same file name exists on the destination folder, the confirmation window for overwriting it will appear. Click [Yes] if you want to overwrite the file, otherwise click [No].





#### 3.7 Create Folder

Select [Tool] → [Create Folder] from the menu or click icon on the tool bar to create a folder in the storage media. Also there is a short cut menu if you right mouse click on the projector view.



#### 3.8 Delete folder or file


Select [Tool] → [Delete] from the menu or click icon on the tool bar to delete a file or folder. Also there is a short cut if you right mouse click on the projector tree view. The confirmation message will appear.



#### 3.9 Assign a file to e-SHOT image

The files on the storage media can be assigned as e-SHOT image from number 1 to 4. Select a file on the projector tree view and choose [Tool] → [Image-n] from the menu or click either 1 2 3 4 icon from the tool bar to assign e-SHOT image. Also there is a short cut menu if you right mouse click on the projector tree. The file format must be ipg, ipg, ipeg, png or bmp.

The file icon is assigned as e-SHOT file changes 1 2 3 4. In addition, you can assign multiple e-SHOT numbers to one file. In that case, the file icon will be shown as icon and can check the actual assignment from that icon status on the tool bar.



#### 3.10 About this Application

You can check the version of this application. Select [Help] → [About Projector File Transfer Tool], or click ?.



## 4 Limitations

- > e-SHOT does not support the following file formats.
  - · Progressive JPEG
  - · 16 bit color depth Bitmap
  - · Interlaced PNG file
- If the network connection is terminated or this tool ends abnormally after you have connected to the projector, the projector's FTP logon remains and you cannot re-connect to the projector with this tool for 20 minutes. If you want to re-connect to the projector immediately, please logon to projector's HTML as the administrator and click the [Restart] button at the Network Restart page, or execute the MIU RESTART by selecting the [MIU] → [SERVICE] → [MIU RESTART] in the projector's advanced menu.

800-328-1371 http://www.3m.com/meetings e-mail: meetings@mmm.com